

2000 - 3000 - 3600 - 3610 MOUNTING MANUAL FOR HYDRAULIC STEERING KIT (USED TO CONVERT FORD 2000 - 3000-3600 - 3610) WITH BY-PASS SYSTEM AND SECURITY VALVE

1. Assemble oil reservoir.
2. Assemble hydraulic oil pump.
3. Mount lift assembly bracketed,
4. Mount left side double pitman arm.
5. Mount right side single pitman arm.
6. Assemble valve and piston.
7. Assemble Drag Lin.
8. The long rod will be installed.
9. 5/8 R6 hose from reservoir to oil pump.
10. Pressure hose 5/16 R1 From oil pump to lift.
11. Return hose 3/8 R6 from lift to reservoir.
12. After mounting use special SAE 10 or 20 to start the engine and check the oil level add some more if necessary.
13. The adjusting screw of the pressure valve.

